

SDRSharp – Scanner Plugin

gui elements & short description

Scanner (Plugin)

Stop

Measuring Mode: Peak Power

Recording: no

Scan Intervall [ms]: 1000

Threshold Release Time [s]: 10

given Trigger Level [dB]: -39

Timeout [s]: 0.2

Peak Power [dB]: -130

Avg B/W Power [dB]: -129

New Edit Delete

Group: 2m

Name	Frequency
Channel_11	145,4875 MHz
Channel_12	145,5125 MHz
Channel_13	145,5375 MHz
Channel_14	145,5625 MHz
Channel_15	145,5875 MHz

Two modes of comparing the given trigger level.

- peak power of the tuned frequency
- the average power level in the channel bandwidth

The waverecorder plugin is used to record automatically the iq/audio stream. Recording is only active as long as the receive level is above the given trigger level. Configure the waverecorder plugin to your needs before enable the recording.

Scan time of one frequency, move on to next frequency after this time if receive level is below the given trigger level

If receive level is above the given trigger level, the current frequency stays tuned. Only If the receive level goes below the given trigger level for the complete threshold time, scanning goes on

Trigger level derived from the scanlist entry

Current value of the calculated timeout before moving on to next frequency in the list

Current peak level of the tuned frequency

current average receive level in the bandwidth

Scan list Manager, same operations as frequency manager plugin. only a few changes

- new field for trigger level
- filtered list (=displayed) list is taken as scanlist
- current tuned frequency is highlighted in the list (blue = scan, green = stay tuned)

SDRSharp – Scanner Plugin

installation notes

to get the plugin running

- copy SDRSharp.Scanner.dll into the SDRSharp directory
- edit SDRSharp.exe.config

goto **<sharpPlugins>** section and add one line as described below

```
<sharpPlugins>
```

```
  <add key="Scanner" value="SDRSharp.Scanner.ScannerPlugin,SDRSharp.Scanner" />
```


```
<sharpPlugins>
```

Tested with

- WIN7, 64Bit
 - SDRSharp Continuous Integration, Last Changed Rev: 1111
 - Terratec NOXON DAB/DAB+ USB dongle (rev 1)
 - ezcap USB 2.0 DVB-T/DAB/FM dongle
-

SDRSharp – Scanner Plugin

states of operation



SDRSharp – Scanner Plugin

infos

Contact

- haocri@gmail.com

Scanner Plugin Source Code

- <https://www.assembla.com/code/sdrsoft/subversion/nodes>

Scanner Plugin Releases

- <https://www.assembla.com/code/sdrsoft/subversion/nodes/trunk/ScannerPlugin/release>
 - v01 – 25.01.2013
-